

MOMENT

MOMENT BAR BOX INSTALLATION GUIDELINES



 Check that the chosen dimensions of the Moment Bar Box correspond with the required concrete cover of the second concreting phase. Ensure that the End Cap (PE Foam) are in place at both ends of casing.



Fix the Moment Bar Box to the formwork and to the reinforcements as well if required.

* Please make sure there is no gap between Moment Bar Box and formwork.



2



MOMENT

3. Cast the concrete in the first phase. Remove the cardboard lid and the End 4. Cap (PE Foam Insert) after removing the formwork. 5. Check that stirrups are completely clean Bend the bars out. It is advisable to use a bending tool to avoid distortion of a bayonet. Bending tool made from 45 degree chamfered tube with an internal diameter just large enough to fit over the bars ribs.

Disclaimer:

Any technical advice/support or drawings provided by us in whatever form is given to the best of our knowledge and for general use only and shall be considered non-binding information

Malaysia

28, Jln Anggerik Mokara 31/59, Kota Kemuning, 40460 Shah Alam, Selangor Tel.: +603 5122 4182 E-Mail: info.my@leviat.com

Singapore Leviat

14 Benoi Crescent Singapore 629977 Tel.: +65 6266 6802 E-Mail: info.sg@leviat.com

India Leviat

309, 3rd Floor, Orion Business Park, Ghodbunder Road, Kapurbawdi, Thane West, Thane, Maharashtra 400607 Tel.: +91 022 2589 2032 E-Mail: info.in@leviat.com

Philippines

U-2933 Regus, Joy Nostalg Centre, #17 ADB Avenue, Ortigas Center, Pasig City 1605 Tel.: +63 2 7957 6381