




MOMENT TERMINATOR JT INSTALLATION GUIDELINES



Steps	Instruction	Diagram
1.	The couplers are to be hand tighten & <u>IN CASE OF SLIGHT RUST, A PIPE WRENCH COULD BE USED TO TIGHTEN.</u>	
2.	Engaged onto extended thread end and forwarded until the end of the thread.	
3.	Make sure the thread is engaged firmly to the coupler terminator and it is ready for use.	

Disclaimer:

Any technical advice/support or drawings provided by us in whatever form is given to the best of our knowledge and for general use only and shall be considered non-binding information.

Malaysia

Leviat

28, Jln Anggerik Mokara 31/59, Kota
Kemuning, 40460 Shah Alam,
Selangor
Tel.: +603 5122 4182
E-Mail: info.my@leviat.com

Singapore

Leviat

14 Benoi Crescent
Singapore
629977
Tel.: +65 6266 6802
E-Mail: info.sg@leviat.com

India

Leviat

309, 3rd Floor, Orion Business Park,
Ghodbunder Road, Kapurbawdi, Thane
West, Thane, Maharashtra 400607
Tel.: +91 022 2589 2032
E-Mail: info.in@leviat.com

Philippines

Leviat

U-2933 Regus, Joy Nostalg Centre,
#17 ADB Avenue, Ortigas Center,
Pasig City 1605
Tel.: +63 2 7957 6381
E-Mail: info.ph@leviat.com