

MOMENT WELDABLE COUPLER INSTALLATION GUIDELINES



Steps	Instruction	Diagram
1.	Weld the Coupler to the position desired by a qualified welder. Welding procedure shall be approved by engineer in charge.	<p>Fillet Weld All Around</p> <p>Welded Part</p>
2.	Engaged onto thread end and forwarded until the end of the thread.	
3.	Make sure the thread is engaged firmly to the coupler and it is ready for use. <u>IN CASE OF SLIGHT RUSTY, A PIPE WRENCH COULD BE USED TO TIGHTEN.</u>	

Disclaimer:

Any technical advice/support or drawings provided by us in whatever form is given to the best of our knowledge and for general use only and shall be considered non-binding information.

Malaysia

Leviat

28, Jln Anggerik Mokara 31/59, Kota Kemuning, 40460 Shah Alam, Selangor
Tel.: +603 5122 4182
E-Mail: info.my@leviat.com

Singapore

Leviat

14 Benoi Crescent
Singapore 629977
Tel.: +65 6266 6802
E-Mail: info.sg@leviat.com

India

Leviat

309, 3rd Floor, Orion Business Park, Ghodbunder Road, Kapurbawdi, Thane West, Thane, Maharashtra 400607
Tel.: +91 022 2589 2032
E-Mail: info.in@leviat.com

Philippines

Leviat

U-2933 Regus, Joy Nostalg Centre, #17 ADB Avenue, Ortigas Center, Pasig City 1605
Tel.: +63 2 7957 6381
E-Mail: info.ph@leviat.com